



TOP VIEW


# PAIL LOADING INSTRUCTIONS

## PROPER LOADING



- NO EAR TO EAR PLACEMENT
- NO EAR TO SIDEWALL PLACEMENT
- ALL BAIL HANDLES FACE INSIDE


## IMPROPER LOADING

- EAR TO EAR PLACEMENT-WRONG
- EAR TO SIDEWALL PLACEMENT-WRONG



TOP VIEW



				TOLERANCE UNLESS SPECIFIED OTHERWISE		<div> <b>Cleveland Steel Container Corporation</b> <b>TECHNICAL CENTER</b> 10048 Aurora Hudson Rd. Streetsboro, Ohio 44241</div>
				FRACTIONAL	±1/32"	
				2 PL. DECIMAL	±.010"	
				3 PL. DECIMAL	±.005"	
				4 PL. DECIMAL	±.001"	
				ANGULAR	±0°30'	
B	ADDED ARROWS	D.W.	3-14-17	DATE:	8-17-2011	TITLE: ~PRODUCT DRAWINGS~ PAIL LOADING INSTRUCTIONS FOR FILLED AND CRIMPED PAIS
A	UPDATED VIEW	D.W.	2-13-17	DRAWN BY:	DAVE WILSON	
REV	DESCRIPTION	BY	DATE	SCALE	1:48	
MATERIAL				SHEET No.	1 of 1	I-PD-004
HEAT TREAT						
						REV B